



## ***Installing VoxPro 4.0***

Insert the CD-ROM into your CD-ROM drive. If the installer does not start right away, browse to your CD-ROM drive and double-click the file *setup.exe*.

After installation is complete, attach your HASP hardware key (dongle) to any open USB port. The hardware wizard should recognize and install the device without errors. (If you are upgrading from VoxPro version 3.2 or 3.3, you'll see that the HASP used by version 4 is not the same! You cannot use your version 3 HASP with VoxPro version 4.)

***New Installations Only:*** Attach your control panel if you have one. If you have ordered the serial control panel, no driver is required. The USB control panel requires a driver, which is located in the *Control Panel Drivers* folder on your VoxPro 4.0 CD-ROM. When you plug in the USB controller, the Windows Hardware Wizard will prompt you for the location of the drivers. You must direct the Wizard to the *Control Panel Drivers* folder on the CD-ROM. Do not allow it to install the default Windows drivers!

Note that we have also included the full Microsoft DirectX9c setup, in the event that you are running an older version. VoxPro requires DirectX 8.0 or higher.

Please contact Audion Labs at +1-206-842-5202 weekdays 9:00 AM to 5:00 PM PST if you encounter any problems with the installation.